



HOW TO HOLD A BOOMERANG THE RIGHT WAY



Put the bar side against your hand.

All return boomerangs are released in a near upright position, at eye level.


THE WRONG WAY. TRUST US.



No return boomerang is ever thrown sideways.

A return boomerang released sideways will rise sharply in the air - and crash. Results in a two piece boomerang.

PREPARING TO THROW



The boomerang should be held secure but loose.

Rotational spin drives the boomerang around the circle.

The throw should follow through after release.

THROWING THE BOOMERANG



Pick a large empty area. A soccer or baseball field is good.

Allow room for bar arm or a gust of breeze. Little or no wind is best when learning.

Locate direction of the breeze with bits of grass.

Throw 45° to the right of the breeze.

When the boomerang circles behind you adjust your next throw air point, more to the right of the breeze, — circles in front throw more to the left.

PREPARING TO CATCH

Do not try to catch a fast returning boomerang.

Wait for a slow, stable hover.

Use gloves — gloves are allowed in competition.

